


# BRASS CORNER GUARDS

Installation Instructions



## Brass Corner Guards – Installation Instructions

### Material/Design Specifications

Brass Corner Guards shall be Muntz brass per specification, one-piece formation with smooth edges, and 3/8" hugger bend. Finish shall be a #4 satin (brushed) or #8 (mirror) finish with a plastic covering to protect the finish during shipping and installation. The corner bend radius of the corner guard will be 1/8". All edges and corners are de-burred. Wing sizes determined per customer's request.

### Using Adhesive

#### STEP 1

Wall surfaces must be clean, dry, and free from dust and grease. Prepare the wall by cleaning the wall surface with mild soap.

#### STEP 2

Using a zig-zag pattern apply construction adhesive (i.e.: Liquid Nails) to each inside wing of the corner guard.

#### STEP 3

Place the corner guard on wall and shift its position slightly to spread adhesive, then remove the corner guard from the wall for one minute to "air", which accelerates drying. After 1 minute reattach the corner guard to the wall.

#### STEP 4

For installation over vinyl wall coverings, follow the above instructions; please be aware that the adhesive will not adhere properly to the vinyl. You will need to cut away a small strip of the vinyl under each wing of the corner guard to adhere to the surface of the wall.

#### STEP 5

Once the corner guard has been installed, remove the protective covering.

---

### Using Screws – 1", #8 Phillips Head

#### STEP 1

Position the corner guard on the wall at the desired location and mark the hole locations on the wall.

#### STEP 2

Drill screw holes at each mark made on the wall.

**STEP 3**

Clean the wall to remove and dust or plaster.

**STEP 4**

Position the guard back on the wall at the desired location and attach to the wall using the factory supplied screws.

**STEP 5**

Once the corner guard is installed, remove the protective covering

---

## Storage & Handling

Store the finished corner guards in a clean and dry area. Material must reach 65° F. min to 75° F. max 24 hours prior to installation.

## Cleaning Instructions

For basic cleaning, including fingerprints, use warm water with a mild soap or an organic solvent (e.g., Acetone, alcohol, methylated spirits), sponge rinse with clean water and wipe dry following the polish lines. For more difficult stains and grease use an organic solvent, mild cleaning, or specialty stainless steel cleaners. Use a sponge, rag, or soft fiber brush to clean, rinse well with a sponge and clean water and wipe dry following the polish lines. Always follow the instructions on all cleaning products prior to use.

## Caution

DO NOT walk on the corner guards.  
DO NOT store anything on top of the corner guards.