Bullnose Metal Corner Guards – Installation Instructions

Using Adhesive

STEP 1
Ensure that the wall surface is dry and clean and free of any dust, dirt, loose paint, wax, oil, or grease by wiping with a solvent.

STEP 2
Using a zig-zag pattern apply construction adhesive (i.e.: Liquid Nails) to each inside wing of the corner guard.

STEP 3
Place the corner guard on wall and shift its position slightly to spread adhesive, then remove the corner guard from the wall for one minute to “air”, which accelerates drying. After 1 minute reattach the corner guard to the wall.

STEP 4
For installation over vinyl wall coverings, follow the above instructions; please be aware that the adhesive will not adhere properly to the vinyl. You will need to cut away a small strip of the vinyl under each wing of the corner guard to adhere to the surface of the wall.

STEP 5
Once the corner guard has been installed, remove the protective covering.

Using Screws – 1", #8 Phillips Head

STEP 1
Position the corner guard on the wall at the desired location and mark the hole locations on the wall.

STEP 2
Drill screw holes at each mark made on the wall.

STEP 3
Clean the wall to remove and dust or plaster.

STEP 4
Position the guard back on the wall at the desired location and attach to the wall using the factory supplied screws.

STEP 5
Once the corner guard is installed, remove the protective covering

Bullnose Vinyl Corner Guards – Installation Instructions

Corner Guards with Double Sided Tape

STEP 1
Ensure that the wall surface is dry and clean and free of any dust, dirt, loose paint, wax, oil, or grease by wiping with a solvent.

STEP 2
If needed, cut the corner guard to the desired length, making sure that all cuts are square and burr free. When cutting, go slow.

STEP 3
Completely remove the backing tape from one wing, then partially remove the backing tape on the second wing. Position the corner guard on the wall and remove the rest of the tape from the second wing. Press firmly along the entire length of the corner guard to ensure adhesion.

Corner Guards with Holes and Screws or Nails

STEP 1
Ensure that the wall surface is dry and clean and free of any dust, dirt, loose paint, wax, oil, or grease by wiping with a solvent.

STEP 2
If needed, cut the corner guard to the desired length, making sure that all cuts are square and burr free. When cutting, go slow.

STEP 3
3/4" WING
Position the corner guard in desired location and press firmly. Hammer the nail through the corner guard into the wall using the factory supplied nails.

1-1/8"-3" WING
Position the corner guard in desired location. Place the self-tapping screws in the pre-drilled counter sunk holes and attach the corner guard to the wall.

Using Adhesive (Provided by Others)

Recommended for attaching to unsealed wood, sealed and unsealed plaster, concrete block, and brick only.

STEP 1

Ensure that the wall surface is dry and clean and free of any dust, dirt, loose paint, wax, oil, or grease by wiping with a solvent.

STEP 2

If needed, cut the corner guard to the desired length, making sure that all cuts are square and burr free. When cutting, go slow.

STEP 3

Using a zig-zag pattern, apply the construction adhesive to each wing of the corner guard.

3" wings	3 beads per wing
2-1/2" wings	3 beads per wing
2" wings	2 beads per wing
1-1/2" wings	2 beads per wing
1-1/8" wings	1 bead per wing
3/4" wings	1 bead per win

STEP 4

Place the corner guard and press firmly until the corner guard has achieved a tight fit. The corner guard may require additional pressure to complete contact with the wall until the adhesive cures. Follow the instructions for the adhesive.

Storage & Handling

Store the finished corner guards in a clean and dry area. Material must reach 65° F. min to 75° F. max 24 hours prior to installation.

Cleaning Instructions

For basic cleaning, including fingerprints, use warm water with a mild soap or an organic solvent (e.g., Acetone, alcohol, methylated spirits), sponge rinse with clean water and wipe dry following the polish lines. For more difficult stains and grease use an organic solvent, mild cleaning, or specialty stainless steel cleaners. Use a sponge, rag, or soft fiber brush to clean, rinse well with a sponge and clean water and wipe dry following the polish lines. Always follow the instructions on all cleaning products prior to use.

Caution

DO NOT walk on the corner guards.
DO NOT store anything on top of the corner guards.