

CHAIR RAILS

Installation Instructions

Polycarbonate Chair Rails - Installation Steps

STEP 1

Ensure that the wall surface is dry and clean and free of any dust, dirt, loose paint, wax, oil, or grease by wiping with a solvent. Ensure that the cleaning solvent will not damage the finish on the wall surface.

STEP 2

Remove the clear protective film on the exposed side of the wall guard.

STEP 3

Place the wall guard at the desired location and height. Verify that the wall guard is level. Mark the pre-drilled holes along the wall.

STEP 4

Drill marked holes on the wall using a 3/16" drill bit. Push a plastic anchor into each hole along the wall, then place the wall guard into position on the wall. Using the provided screws attach the wall guard to the wall.

Cutting Polycarbonate

Due to the tough nature of polycarbonate chair rails, TheCornerGuardStore does not recommend cutting the chair rails in the field. The corner guard material when cut with a power saw can cause the saw to kick back and injure the operator. For custom lengths call before placing an order and TheCornerGuardStore can cut the parts to size in the manufacturing process. If cutting is absolutely required, use a hacksaw, go slow and be careful.

Storage & Handling

This is a finished product, store in a clean and dry area. Material must reach 65° F. min to 75° F. max 24 hours prior to installation.

Cleaning Instructions

For routine cleaning, including fingerprints, use warm water with a mild soap or an organic solvent (eg. Acetone, alcohol, methylated spirits), sponge rinse with clean water and wipe dry following the polish lines. For tougher stains and grease use an organic solvent, mild cleaning, or specialty stainless steel cleaners. Use a sponge, rag, or soft fiber brush to clean, rinse well with a sponge and clean water and wipe dry following the polish lines. Always read the instruction and warning label on all cleaning products before use.

Caution

DO NOT walk on the corner guards.
DO NOT store anything on top of the corner guards.