

# POLYCARBONATE / LEXAN

Installation Instructions



## Adjustable Angle Corner Guards – Installation Instructions

### STEP 1

Wall surfaces must be clean, dry, and free from dust and grease. Wipe the wall surface with a solvent to assure all grease, loose paint, dust and dirt are removed. Make sure that the cleaning solvent used will not damage the finish on the wall surface.

### STEP 2

Remove the backing on the double-sided tape on the corner guard.

### STEP 3

Position the inner center apex of the corner guard to the desired corner of the wall. Press the sides/ wings of the corner guard tightly to the wall.

### STEP 4

Apply firm pressure to the entire surface of each wing of the corner guard to ensure a proper solid bond with the wall surface.

---

## Cutting Polycarbonate

The adjustable clear corner guard comes in standard 4' and 8' lengths. It can easily be cut with a saw to create any desired custom length. A compound miter saw, with a 80- 100 carbide tipped blade, or a hack saw can be used to cut the corner guards to length in the field. Be sure when cutting to follow the safety requirements for the saw you are using and to wear safety glasses.

## Storage & Handling

This is a finished product, store in a clean and dry area. Material must reach 65° F. min to 75° F. max 24 hours prior to installation.

## Cleaning Instructions

### STEP 1

For best results, the use of liquid cleaners such as “409,” “Fantastic,” and “Mr. Clean,” etc. are recommended. The use of powder cleansers is not recommended. Use of such cleansers can leave residue which is difficult to remove.

### STEP 2

Do not use chlorinated or aromatic hydrocarbons, esters, or ketones to clean Wallprotex vinyl products. Avoid the use of heavy degreasers, compounds containing surfactants, and abrasive compounds or cleaning devices.

## Caution

DO NOT walk on the corner guards.

DO NOT store anything on top of the corner guards.