

POLYCARBONATE / LEXAN

Installation Instructions



Polycarbonate – “Lexan” Corner Guards – Installation Instructions

Corner Guards with Holes and Screws or Nails

STEP 1

Ensure that the wall surface is dry and clean and free of any dust, dirt, loose paint, wax, oil, or grease by wiping with a solvent. Ensure that the cleaning solvent will not damage the finish on the wall surface.

STEP 2

Remove the clear protective film on the exposed side of the corner guard.

STEP 3

3/4” WING

Place in desired location and hold the corner guard firmly. Using factory supplied nails, hammer the nail through the corner guard into the wall.

1-1/8”-3” WING

Place in desired location and hold the corner guard firmly. Attach the corner guard by placing the provided self-tapping screws in the pre-drilled counter sunk holes and attach to the wall.

Corner Guards with Double Sided Tape*

STEP 1

Wall surfaces must be clean, dry and free from dust and grease. Wipe the wall surface with a solvent to assure all grease, dust, and dirt are removed. Make sure that the cleaning solvent used will not damage the finish on the wall surface.

STEP 2

Remove the clear protective film on the exposed side of the corner guard (clear corner guards only).

STEP 3

Peel off backing tape from one wing entirely, then peel back the tape partially on the second wing. Place wing with the fully exposed tape to the wall, then remove the remainder of the tape backing from the second wing. Press firmly along the entire length of the corner protector to ensure a good bond.

Cutting Polycarbonate

Due to the tough nature of polycarbonate corner guards, TheCornerGuardStore does not recommend cutting the corner guards in the field. The corner guard material when cut with a power saw can cause the saw to kick back and injure the operator. For custom lengths call before placing an order and TheCornerGuardStore can cut the parts to size in the manufacturing process. If cutting is absolutely required, use a hacksaw, go slow and be careful.

Storage & Handling

This is a finished product, store in a clean and dry area. Material must reach 65° F. min to 75° F. max 24 hours prior to installation.

Cleaning Instructions

For routine cleaning, including fingerprints, use warm water with a mild soap or an organic solvent (eg. Acetone, alcohol, methylated spirits), sponge rinse with clean water and wipe dry following the polish lines. For tougher stains and grease use an organic solvent, mild cleaning, or specialty stainless steel cleaners. Use a sponge, rag, or soft fiber brush to clean, rinse well with a sponge and clean water and wipe dry following the polish lines. Always read the instruction and warning label on all cleaning products before use.

Caution

DO NOT walk on the corner guards.

DO NOT store anything on top of the corner guards.