

POWDERCOATED CORNER GUARDS

Installation Instructions



Powdercoated Corner Guards – Installation Instructions

STEP 1

Ensure that the wall surface is dry and clean and free of any dust, dirt, loose paint, wax, oil, or grease.

STEP 2

Using a zig-zag pattern, apply the construction adhesive to each wing of the corner guard.

STEP 3

Place the corner guard and press firmly until the corner guard has achieved a tight fit. The corner guard may require additional pressure to complete contact with the wall until the adhesive cures.

STEP 4

Once installation is completed, remove the protective covering.

Storage & Handling

Store the finished corner guards in a clean and dry area. Material must reach 65° F. min to 75° F. max 24 hours prior to installation.

Cleaning Instructions

For basic cleaning, including fingerprints, use warm water with a mild soap or an organic solvent (e.g., Acetone, alcohol, methylated spirits), sponge rinse with clean water and wipe dry following the polish lines. For more difficult stains and grease use an organic solvent, mild cleaning, or specialty stainless steel cleaners. Use a sponge, rag, or soft fiber brush to clean, rinse well with a sponge and clean water and wipe dry following the polish lines. Always follow the instructions on all cleaning products prior to use.

Caution

DO NOT walk on the corner guards.
DO NOT store anything on top of the corner guards.