VINYL CORNER GUARDS

Installation Instructions



Corner Guards with Double Sided Tape

STFP 1

Ensure that the wall surface is dry and clean and free of any dust, dirt, loose paint, wax, oil, or grease by wiping with a solvent.

STEP 2

If needed, cut the corner guard to the desired length, making sure that all cuts are square and burr free. When cutting, go slow.

STEP 3

Completely remove the backing tape from one wing, then partially remove the backing tape on the second wing. Position the corner guard on the wall and remove the rest of the tape from the second wing. Press firmly along the entire length of the corner guard to ensure adhesion.

Corner Guards with Holes and Screws or Nails

Ensure that the wall surface is dry and clean and free of any dust, dirt, loose paint, wax, oil, or grease by wiping with a solvent.

STEP 2

If needed, cut the corner guard to the desired length, making sure that all cuts are square and burr free. When cutting, go slow.

STEP 3

3/4" WING

Position the corner guard in desired location and press firmly. Hammer the nail through the corner guard into the wall using the factory supplied nails.

1-1/8"-3" WING

Position the corner guard in desired location. Place the self-tapping screws in the pre-drilled counter sunk holes and attach the corner guard to the wall.



Using Adhesive (Provided by Others)

Recommended for attaching to unsealed wood, sealed and unsealed plaster, concrete block, and brick only.

STFD 1

Ensure that the wall surface is dry and clean and free of any dust, dirt, loose paint, wax, oil, or grease by wiping with a solvent.

STEP 2

If needed, cut the corner guard to the desired length, making sure that all cuts are square and burr free. When cutting, go slow.

STEP 3

Using a zig-zag pattern, apply the construction adhesive to each wing of the corner guard.

3" wings	3 beads per wing
2-1/2" wings	3 beads per wing
2" wings	2 beads per wing
1-1/2" wings	2 beads per wing
1-1/8" wings	1 bead per wing
3/4" wings	1 bead per win

STEP 4

Place the corner guard and press firmly until the corner guard has achieved a tight fit. The corner guard may require additional pressure to complete contact with the wall until the adhesive cures. Follow the instructions for the adhesive.

Storage & Handling

Store the finished corner guards in a clean and dry area. Material must reach 65° F. min to 75° F. max 24 hours prior to installation.

Cleaning Instructions

STEP 1

For best results, the use of liquid cleaners such as "409," "Fantastic," and "Mr. Clean," etc. are recommended. DO NOT use powder cleansers as they can leave difficult to remove residue.

STEP 2

Do not use chlorinated or aromatic hydrocarbons, esters, or ketones to clean TheCornerGuardStore vinyl products. Avoid the use of heavy degreasers, compounds containing surfactants, and abrasive compounds or cleaning devices.

Caution

DO NOT walk on the corner guards.

DO NOT store anything on top of the corner guards.

