

STORAGE & HANDLING

The corner guards are shipped unassembled. Upon receipt, the vinyl corner guards should be stored in the horizontal position at room temperature (65 - 75° F). This is a finished product; store in a protected, clean, dry area away from direct sunlight.

CAUTION!

DO NOT WALK ON THE CORNER GUARDS.
DO NOT STORE ANYTHING ON TOP OF THE CORNER GUARDS.

INSTALLATION PROCEDURE

Corner Guards with Double Sided Tape

STEP 1. Wall surfaces must be clean, dry, and free from dust and grease. Wipe the wall surface with a solvent to assure all grease, dust and dirt are removed. Make sure that the cleaning solvent used will not damage the finish on the wall surface.

STEP 2. If required, cut corner guard to required length, ensuring that all cuts are square and burr free.

STEP 3. Peel off backing tape from one wing entirely, then peel back the tape partially on the second wing. Place wing with the fully exposed tape to the wall, then remove the remainder of the tape backing from the second wing. Press firmly along the entire length of the corner protector to ensure a good bond.

INSTALLATION PROCEDURE

Corner Guards with Holes and Screws or Nails

STEP 1. Wall surfaces must be clean, dry, and free from dust and grease. Wipe the wall surface with a solvent to assure all grease, dust and dirt are removed. Make sure that the cleaning solvent used will not damage the finish on the wall surface.

STEP 2. If required, cut corner guard to required length, ensuring that all cuts are square and burr free.

STEP 3.

For 3/4" wing corner guards

Place in desired location, hold the corner guard firmly. Using factory supplied nails, hammer the nail through the corner guard into the wall.

For 1-1/8" - 3" wing corner guards

Place in desired location, hold the corner guard firmly. Attach the corner guard by placing the provided self tapping screws in the pre-drilled counter sunk holes and attach to the wall.

INSTALLATION PROCEDURE

Using Adhesive (Provided by Others)

NOTE: Recommended for attaching to unsealed wood, sealed and unsealed plaster, concrete block and brick only.

STEP 1. Wall surfaces must be clean, dry, and free from dust and grease. Wipe the wall surface with a solvent to assure all grease, dust and dirt are removed. Make sure that the cleaning solvent used will not damage the finish on the wall surface.

STEP 2. If required, cut corner guard to required length, ensuring that all cuts are square and burr free.

STEP 3. Apply 3/16" beads of adhesive to each wing of the protector following application chart below.

- 3" Wings 3 beads per wing
- 2-1/2" Wings 3 beads per wing
- 2" Wings 2 beads per wing
- 1-1/2" Wings 2 beads per wing
- 1-1/8" Wings 1 bead per wing
- 3/4" Wings 1 bead per wing

STEP 4. Place the corner protector on the corner and push firmly into position. Be sure to use an acceptable vinyl adhesive, such as liquid nails, and to follow the usage instruction on the adhesive.

CLEANING INSTRUCTIONS

1. For best results, the use of liquid cleaners such as "409", "Fantastic", "Mr. Clean", etc. are recommended. The use of powder cleansers is not recommended, use of such cleaners can leave residue which is difficult to remove.
2. Do not use chlorinated or aromatic hydrocarbons, esters or ketones to clean TheCornerGuardStore's vinyl products. Avoid the use of heavy degreasers, compounds containing surfactants, and abrasive compounds or cleaning devices.

